



1. CUT RED WIRES FROM PC BOARD
2. REMOVE DEFECTIVE PC. BOARD
3. INSTALL NEW PC. BOARD
4. SPLICE RED WIRES AS SHOWN ON DIAGRAM