

Guard Phone Module Installation Instructions

The TX3-GPM Guard Phone Module mounts above the **TX3 Entry Panel Main board** on the top left hand side, using the four # 6-32 screws and spacers provided. The ribbon cable from the TX3-GPM connects to the **P7** connector on the **TX3 Entry Panel Main board**. The guard phone connects via a telephone cable to the telephone jack on the board.

To install the TX3 TX3-GPM Guard Phone Module

1. Connect the ribbon cable, then place the board over the connector position with the four spacers.
2. Align, and fasten into place with the four screws..

Install the TX3 - GPM Guard Phone Module on the main board in this location.

Connect to P7 using the ribbon cable from the TX3 - Guard Phone module

P7 Connector is located on the TX3 Entry Panel main board beneath the TX3 - GPM module.

